iPad Use and Care Instructions for Families



Basics

- Off and ON push and hold the <u>Sleep/wake</u> button on top right of the iPad. If already on, push the <u>Home</u> button and slide your finger to the right along the arrow to unlock
- Slide your finger to the right along the screen to change pages
- The iPad can be positioned either vertically or horizontally for use
- To return to the home screen (menu pages) push the Home button

Applications (apps)

- Touch the desired app to open. Some apps will only work in only one direction (horizontally or vertically)
- Decline all prompts on the screen to rate an app, allow notifications or to buy a full version
- All apps needed for a child and family to use to achieve IFSP outcomes will be downloaded onto the iPad by a CDSA staff member



The gears icon on home screen will allow you to change the settings for apps, if needed. There will be list of apps on the bottom left of the screen after you touch the settings icon.

Internet

- All iPads can access the internet with available Wi-Fi.
 - The Infant Toddler program loaner iPads are for use as Assistive Technology with the enrolled child as indicated on the child's IFSP.
 - The loaned iPad should not be used by family members for internet browsing, or to access personal email.

Battery / Charging

- The iPad indicates in the top right corner the battery charge remaining. Charge the iPad when convenient but at least weekly. The battery life is approximately 10 hours.
- To charge, plug the wider flat end of the charging cord into the slot on the bottom of the iPad below the <u>Home</u> button. You may have to take the iPad out of the case to charge.
- When properly charging, a lightning bolt will appear next to the battery icon in the top corner of the iPad.



Care and Cleaning

- Use a safe distance from water to avoid accidentally dropping into water. Water will damage the iPad beyond repair.
- To clean, unplug all cables and turn off the iPad. Use a soft, slightly damp, lint-free cloth. Avoid getting moisture in openings.
 Do not use window cleaners, household cleaners, aerosol sprays, solvents, alcohol, ammonia, or abrasive cleaners.

For any technical questions with apps or with the iPad, contact the CDSA Assistive Technology Contact.

Name:			
Phone Number:			